

Labor-saving, versatile means for hanging static load HVAC Systems

- Meets SMACNA upper and lower attachment construction standards if used per manufacturer's installation guidelines
- Comprehensive Clutcher Hanging System Load Charts and Installation Videos available online at Ductmate.com
- Seismic tested and conforms to ICC Code guidelines AC284
- · Engineered for strength and durability
- Tapered bore design for fast and easy installation

- Eliminates the need to stock multiple lengths of cable
- Compact design is aesthetically pleasing
- Easily adjust hanging height by hand
- Available in 2 sizes to meet specific load ranges
- Items can be hung at angles up to 60° from vertical

IMPORTANT INFORMATION


Before use or installation of product, read and follow all product information and warnings. Do not use product in a manner that is inconsistent with the manufacturer's printed information. Ensure that all employees installing the Clutcher System have been properly trained on the use of this product.







DESCRIPTION



The Ductmate Clutcher System is a complete Steel Cable hanging system for HVAC Systems.

The Ductmate Clutcher Cable Hanging System consists of Ductmate Clutcher Cable and the Ductmate Clutcher mechanism. For the system to work properly, both components must be used. Ductmate Clutcher Cable is the only cable tested and approved for use with the Ductmate Clutcher system. Use of any other cable is prohibited, and will void the Ductmate warranty.

The Clutcher mechanism uses a serrated steel wedge to grip the Clutcher Cable (fig. A1). The housing of the mechanism is cast out of metal. The shape and orientation of the wedge allows Clutcher Cable to pass through in one direction. When a load is applied to the Clutcher Cable in the opposite direction, the wedge grips the Clutcher Cable and presses it against the Clutcher mechanism housing, preventing it from moving (fig. A2).

The Clutcher mechanism has two bores or passages. The first bore allows the Clutcher Cable to pass freely through the housing; the second bore contains the wedge mechanism described above.

BASIC USE

Labor-saving, versatile means for the suspension of static load HVAC Systems.

SPECIAL CHARACTERISTICS

- Meets SMACNA upper and lower attachment construction standards if used per manufacturer's installation guidelines
- Seismic tested and conforms to ICC Code guidelines AC284
- Engineered for strength and durability
- Tapered bore design for fast and easy installation
- Eliminates the need to stock multiple lengths of cable

- Compact design is aesthetically pleasing
- Easily adjust hanging height by hand
- Available in 2 sizes to meet specific load ranges
- Items can be hung at angles up to 60° from vertical
- Comprehensive Clutcher Hanging System Load Charts available online at Ductmate.com

TECHNICAL INFORMATION

Clutcher Mechanism

HOUSING: Zinc Cast WEDGE: Hardened Steel

SPRING: Steel END CAP: Zinc

Clutcher Cable

This system requires that Ductmate Clutcher Cable be used to meet testing and product specifications.

SAFETY

The Clutcher system has been engineered and tested to meet SMACNA upper and lower attachment safety standards. The vertical load limit of the system is the maximum amount that can be supported. When designing a system, do not exceed the load limit of the Clutcher system.

VERTICAL LOAD LIMITS

Clutcher System	Maximum Load	Required Clutcher Cable
CL10	125 lbs. (56.7 kg)	WR10
CL20	250 lbs. (113.4 kg)	WR20

The Ductmate Clutcher System and Ductmate Clutcher Cable must always be used in conjunction. Use of any other steel cable is prohibited.

PACKAGING INFORMATION


Size	Box Quantity	Bag Quantity	Bag/Boxes
CL10	500	10	50
CL20	400	10	40

CAUTION


- Never exceed the WORKING LOAD LIMIT. In calculating working load, the full weight of the duct with contents, controls, and accessories must be calculated.
- Loads should be carried evenly across all hanging points.
- · Always check that the locking mechanism is fully engaged.
- Do not use the Clutcher hanging system for lifting.
- Do not apply paint, lubricants or other coatings to the Clutcher system.
- Advise all applicable parties and post notices as necessary to ensure that paint, lubricants, and/or other coatings are not applied during the installation or in the future.
- Do not use in corrosive or extremely humid conditions. Such conditions, over time, can cause metal components to corrode and fail.
- Use only with static loads. Not intended for use with oscillating loads.
- Prior to use, store product in a clean, dry and safe condition.
- Care should be taken that sharp edges do not come in contact with the system and abrade or damage the Clutcher Cable.
- When adjusting or disconnecting Clutcher system, always make sure that load is fully supported by other means.
- Be sure the building structure is capable of supporting the weight of the load.
- Use an appropriate hanging method to prevent lateral movement in suspended duct.
- Do not use the Standard Loop Configuration with duct over 18" in diameter.
- Do not use the Standard Loop or Single Point Saddle Configuration with rectangular duct.
- · Do not stand or walk on duct system.
- When used as a supplementary support, duct being suspended cannot exceed maximum load rating of the Clutcher system.
- For extreme temperature ranges consult design engineer.
- Do not reuse cable once when Clutcher mechanism has been disengaged.
- Reference Clutcher Duct Construction Standards.

ASSEMBLY EXAMPLES


ROUND OR OVAL DUCT



RECTANGULAR DUCT




SIDE LOADINGS



CLUTCHER MECHANISM DIRECTIONS


Attaching the Clutcher mechanism to the Clutcher Cable is quick and easy. Insert the Clutcher Cable through the free bore side, starting on the wider end of the Clutcher mechanism. Loop the Clutcher Cable around the upper attachment point, and into the wedge side of the Clutcher mechanism on the narrower end. There are arrows cast into the Clutcher mechanism body that indicate which way to insert the Clutcher Cable. At least 3" (76.2mm) of Clutcher Cable should be extending out of the Clutcher mechanism housing. Repeat the process with a second Clutcher unit to cradle the load.

* Tip: When cutting Clutcher Cable, use a quality cutter designed for Clutcher Cable. Tin snips, diagonal cutters, and electrical cable cutters will not work; they will fray the ends of the Clutcher Cable and prevent it from sliding into the Clutcher mechanism correctly.



WARNING


DO NOT attempt to use the Clutcher mechanism to splice two cables together, or attempt to secure the Clutcher Cable via only one bore in the Clutcher mechanism. The same Clutcher Cable must pass through both bores in the Clutcher mechanism.






INSTALLATION INSTRUCTIONS


After the ductwork is leveled and the connection at the upper attachment is secured with the Ductmate Clutcher Cable, then proceed with attaching the Clutcher mechanism to the duct being suspended.




 Insert Clutcher Cable through free flowing side of Clutcher mechanism.



3. Wrap cable around duct being suspended.



2. Loop cable through eye bolt and into locking mechanism of Clutcher



 Loop cable through the same eye bolt as in step 2 and secure with a second Clutcher using same method as step 1 and 2

WARNING - Before Installation is Completed

Make sure the load is evenly distributed over ALL Clutcher mechanisms and that ALL Clutcher mechanisms are engaged.

LIMITED PRODUCT WARRANTY

Ductmate warrants that Clutcher, when properly installed and maintained, will be free from defects in material and workmanship, and will comply with all written specifications made by Ductmate at the time of sale. Ductmate's warranty shall run for a period of one year from the date of manufacture.

Warranty Limitation

The warranty stated above is in lieu of all other warranties, express or implied, including but not limited to the implied warranties of MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Although Ductmate may have suggested the product, or provided written or oral advice to the Purchaser, it is the Purchaser's responsibility to test and determine the suitability of Clutcher, for the intended use and purpose, and Purchaser and/or its customer assumes all risk and liability whatsoever regarding such suitability.

Limitation of Liability

In the event of a breach of the above warranty, Ductmate's sole obligation, and Purchaser's sole and exclusive remedy, shall be, at Ductmate's option, repair or replacement of any defective products, or refund of an applicable portion of the purchase price. Ductmate shall have no liability for costs of removal or reinstallation of the product. The Purchaser agrees that no other remedy, including but not limited to loss of profits, loss sales, injury to person or property, or any other special, incidental or consequential damages, shall be available to the Purchaser for any claim arising out of this Agreement, regardless of whether such claim is made in contract or in tort, including strict liability in tort. In no event will Ductmate be obligated to pay damages to the Purchaser in any amount exceeding the purchase price that the Purchaser paid to Ductmate for the allegedly defective product.

HANGING CONFIGURATIONS

The type of hanging configuration used depends on the application. The following hanging configurations apply to round or oval ductwork only. For rectangular ductwork, use Standard or Spread Horseshoe configuration. It is up to the end user to determine the best configuration for their particular installation.

The first method is called the single point saddle method (**fig. 1**). This method is to be the primary hanging method when using the Clutcher mechanism. The Clutcher Cable is looped through an eye bolt that is attached to the top support and then secured with a Clutcher. The same cable is then looped around the duct and back through the same eye bolt, then secured with a second Clutcher. This method ensures that the working load limit of the Clutcher is not adversely affected when larger duct is used.

The second method is the standard horseshoe (fig. 2). In this method, the Clutcher Cable is looped around the upper support and secured with a Clutcher mechanism, then routed under the ductwork and back up to the upper support to be secured with another Clutcher mechanism. This method helps to eliminate some swinging in the ductwork. Using two Clutcher mechanisms on a single cable at separate attachment points, does not change the maximum stated load rating. When supported in this fashion, the tension in the Clutcher Cable is reduced by half. This mechanical advantage is the same concept that makes a block and tackle work. This configuration can be used for general purpose hanging when an increased factor of safety is desired.

Next is the spread horseshoe method (**fig. 3**). This is the same layout as above, but the Clutcher Cables are spread to the side, creating a measure of cross bracing. Since the Clutcher Cables are on an angle in this method, there is a reduction in their working load limit. This configuration can be used when additional stability is desired. Items can be hung at angles up to 60° from vertical.

We'll call the last method the standard loop (**fig. 4**). The Clutcher Cable is looped around the upper support and secured with a Clutcher mechanism, then looped around the duct and secured with another Clutcher mechanism. The advantage of this method is its simplicity. It is suitable for applications where the duct will not experience lateral forces or be prone to swinging. An example of this would be a duct that is attached to a wall or other fixed element on each end. This configuration can be used for general purpose hanging. **The standard loop** is only permitted for use on round duct diameters 18" or less, and on oval duct with a major axis of 18" or less.

MAXIMUM LOADS FOR NON-VERTICAL SUPPORT


(Table 1: Load Limits) *				
Angles from Vertical	Maximum Load for Clutcher Mechanism			
(in degrees)	CL10	CL20		
0	125.0 lbs (56.7 kg)	250.0 lbs (113.4 kg)		
5	124.5 lbs (56.5 kg)	249.0 lbs (112.9 kg)		
10	123.1 lbs (55.8 kg)	246.2 lbs (111.7 kg)		
15	120.7 lbs (54.7 kg)	241.5 lbs (109.5 kg)		
20	117.5 lbs (53.3 kg)	234.9 lbs (106.6 kg)		
25	113.3 lbs (51.4 kg)	226.6 lbs (102.8 kg)		
30	108.3 lbs (49.1 kg)	216.5 lbs (98.2 kg)		
35	102.4 lbs (46.4 kg)	204.8 lbs (92.9 kg)		
40	95.8 lbs (43.5 kg)	191.5 lbs (86.9 kg)		
45	88.4 lbs (40.1 kg)	176.8 lbs (80.2 kg)		
50	80.3 lbs (36.4 kg)	160.7 lbs (72.9 kg)		
55	71.7 lbs (32.5 kg)	143.4 lbs (65.0 kg)		
60	62.5 lbs (28.4 kg)	125.0 lbs (56.7 kg)		

Comprehensive Load Charts and Installation Videos available online at ductmate.com


HANGING ON AN ANGLE

When using the spread horseshoe method, the tension in the Clutcher Cable increases. Table 1 shows the reduced working load limits for each size of Clutcher mechanism, determined by the angle in the Clutcher Cable.


Single Point Saddle




Standard Horseshoe



Spread Horseshoe



Standard Loop




STABILITY IN THE DUCT SYSTEM

When installed, the duct system should be stable enough that it doesn't swing or move when in use. Excessive movement can lead to fatigue failures in the joints or connections.


Typically, a duct run will be attached to some rigid object, such as a wall or equipment at one or both ends of the run.

When a run of duct is anchored only at one end, and cantilevered outward, the free end of the run can be expected to swing laterally (fig. 5a). When a long run of duct is anchored at both ends, the free center of the duct run may swing laterally (fig. 5b). If two sections of duct anchored at one end converge at a 90° angle (fig. 5c), free sections of duct may swing laterally.

In an application where movement is not expected, the single point saddle method (fig. 1), the standard horseshoe method (fig. 2), and the standard loop (fig. 4) can be used. When lateral movement needs to be minimized, the spread horseshoe (fig. 3) should be used.



CLUTCHER CABLE



DESCRIPTION

Aircraft quality zinc coated Clutcher Cable available in 7 x 7 thread type.

BASIC USE

Ductmate Clutcher Cable is designed for the suspension of HVAC systems. The Ductmate Clutcher System and Ductmate Clutcher Cable Must Always be Used In Conjunction. Use Of Any Other Steel Cable Is Prohibited.

SPECIAL CHARACTERISTICS

- Ductmate Clutcher Cable can be easily recognized by the unique red thread woven into the cable
- Engineered for superior strength
- Supplied in spools of 500' and 1,000' to reduce waste Available in 2 diameter sizes to match each Clutcher mechanism


PACKAGING INFORMATION - 7 X 7

Part Number	Length	For Use With
WR10500	500' Spool	CL10
WR101000	1,000' Spool	CL10
WR20500	500' Spool	CL20
WR201000	1,000' Spool	CL20

ACCESSORIES

WARNING

When adjusting a Clutcher mechanism, be sure that the load is supported by alternate means before pulling back on the wedge and releasing the Clutcher Cable.



Ductmate DeClutcher

A custom hand tool designed to quickly and easily release the wedge on the Clutcher mechanism (CL10 and CL20 only), in order to release the Clutcher Cable from the Clutcher mechanism.

(Part Number: CLTOOL1020).



Ductmate Light Duty Clutcher Cable Cutter

A small, high-quality cutter designed for Clutcher Cable. Tin snips, diagonal cutters, and electrical Cable cutters fray the ends of the Clutcher Cable and prevent it from sliding into the Clutcher mechanism correctly. The Ductmate Clutcher Cable Cutter provides a clean cut with less effort.

(Part Number: HFWRC model shown works with Ductmate Clutcher Cable part numbers WR10 & WR20.)



Rectangular Duct Corner Saddles

The Corner Saddle is designed to eliminate abrasion of rectangular ductwork with the use of a Clutcher Cable hanging system. Corner Saddles can be used when hanging rectangular duct with Ductmate's Clutcher/Wire Rope System. For WR10 and WR20.

(Part Number: HFCCS)



Charleroi. PA 210 Fifth Street Charleroi, PA 15022 724-258-0500

Lodi, CA 810 S. Cluff Avenue

Lodi, CA 95240-9141 209-333-4680

Additional Manufacturing and Warehousing in Monongahela, PA and Wagoner, OK

1-800-245-3188 • www.ductmate.com © Copyright Ductmate Industries, Inc. All rights reserved.



Ductmate Is A Proud Member Of The Following Organizations:







Distributed By: